LS9140 Quadralux LS9120 Quadralux






### READ ALL SAFETY INSTRUCTIONS FIRST


- > Follow instructions carefully, failure to do so will void warranty.
- > Ensure installation complies with local law and applicable standards.
- > Input voltage is 120-277 V AC, 50/60 Hz
- > Only use Lumascape power supply, control equipment and leader cables.
- > Ensure mains input power is surge protected.

- > Never make connections whilst the power is connected.
- > Do not make modifications or alter the product.
- > Keep luminaire and connections clean and free of debris and moisture.
- > It is the installers responsibility that the installation is adequately sealed to avoid moisture ingress.



ARCHITECTURAL SPOTLIGHT **FACADE LUMINAIRE** 






ARCHITECTURAL SPOTLIGHT **FACADE LUMINAIRE** 



## Safety Cable Attachment



Be sure to use spring washers provided (between screw head and safety anchor) to ensure screws don't loosen over time.

## **Attach Safety Cable**

Attach the safety cable to the bracket. Minimum break load for cable must be ≥1,020 kg

## **Attach Safety Cable**

Attach the other end of the safety cable to a structural component in a suitable manner.

# **QUESTIONS** Contact us at details below.

LUMASCAPE ASIA PACIFIC Brisbane Technology Park, 18 Brandl Street, Eight Mile Plains, QLD 4113, Australia Phone +61 7 3854 5000 | Fax +61 7 3854 5001 | Email: sales@lumascape.com.au | www.lumacape.com